



## NOTE 7 Using Eight Adapters

---

It is possible to put up to eight ASI4200, ASI5111, and ASI6100 series adapters in a computer (provided you have enough PCI slots).

For ASI6100 adapters you need driver v2.89 or later

Since the adapters only have a 4 position header, adapter indexes 5 through eight must be specified using a binary encoding of the header.

Here's how you do it:

Adapter Index	Header Jumpering
1	
2	
3	
4	
5	
6	
7	
8	

[end]